


## Introduction

The Create phasing window is the main interface from which you will organize all the components of your phasing:

Create phasing

- [Introduction](#)
- [Drawings management](#)
- [GIS management](#)
- [Areas and axes management](#)
- [Print areas management](#)
- [Tasks management](#)
- [Connected objects management](#)
- [Mobile pictograms \(v6 features\)](#)
- [The Gantt chart](#)
- [The Live View \(v6 features\)](#)



The screenshot displays the software interface with a map view on the left and a Gantt chart on the right. The map shows a road layout with various construction zones and axes. The Gantt chart below the map lists activities with their start and end dates and phases.

Num (PM)	Debut (PM)	Fin (PM)	Mar	Jun	Juillet
CLIQUEZ SUR UNE ZONE / PHASE	14/05/2018 08:00	13/06/2018 15:00		CLIQUEZ SUR UNE ZONE / PHASE	
Démolition bordures et pavés	22/05/2018 08:00	24/05/2018 15:00	Démolition bordures et pavés		
Démolition bordures et pavés	22/05/2018 08:00	24/05/2018 15:00	Démolition bordures et pavés		
Elargissement chaussée + fouilles + c.	30/05/2018 08:00	01/06/2018 15:00	Elargissement chaussée + fouilles + canalisations		
Elargissement chaussée + fouilles + c.	30/05/2018 08:00	01/06/2018 15:00	Elargissement chaussée + fouilles + canalisations		
Passage de chaussée	13/06/2018 08:00	13/06/2018 15:00	Passage de chaussée		