

Deliverables management levels


Deliverables management

- Introduction
- **Deliverables management levels**
- The different types of deliverables
- Creating deliverables
- Copy and/or update a deliverable
- Customizing deliverables
- Managing statuses
- Clipping drawings in deliverables

The deliverable management interface has evolved in version 4, with four levels of parameterization:

- Deliverables
- Page
- Columns
- Map / Drawing

A fifth tab allows you to set colors for the status of areas and axes.



Deliverables

This tab allows you to set for the whole deliverable:

Areas color

The color applie to areas and axes:

- Status color: defined in the “Areas and axes status” tab
- Area/Axis color: defined in the Create phasing interface
- Task field: based on custom fields

Page format

- Page layout used: including columns
- Page size: A0 → A5
- Orientation and margins

Page

This tab allows you to define page by page :

- **Printing area** used
- **Zoom level** applied (on display)
- **Options**: if you want to display chart legends (Gantt, Time line...) and KPs
- **Labels**:
 - **model** and **size** of lables
 - automatic placement tool
 - option: if you wish to display them and their links

Columns

This tab allows you to insert Objects, Tasks fields and Legends. It also allows you to decide if you want to display the Scale if it exists.

Objects

Allows you to insert shapes, polylines, polygons, texts or images.

Tasks fields

Allows you to insert the name of the phase, as well as the start and end dates of the page.

Chart legends

Allows you to insert :

- Status legend
- Areas legend
- Time scale

- Gantt chart

Map / Drawing

Allows you to insert Objects as for the columns, but directly on the drawing.

It is from this tab that you can also add a dimension with the measurement tool.

Areas and axes status

This tab allows you to choose the status colors.