

Phase Manager modules

- **Create phasing**
 - Introduction
 - Drawings management
 - GIS management
 - Areas and axes management
 - Print areas management
 - Tasks management
 - Connected objects management
 - Mobile pictograms (v6 features)
 - The Gantt chart
 - The Live View (v6 features)
- **Tasks**
 - The tasks management interface
- **Labels and areas conditions**
 - Areas conditions and labels management
- **Deliverables management**
 - Introduction
 - Deliverables management levels
 - The different types of deliverables
 - Creating deliverables
 - Copy and/or update a deliverable
 - Customizing deliverables
 - Managing statuses
 - Clipping drawings in deliverables
- **Page layout**
 - Creation of printing templates
- **Printing**
 - Printing deliverables
- **Calendars management**
 - Calendars management
- **File menu**
 - Import Export
 - Exporting the project's KML
 - Save project as a template
 - Archive a project
- **Options menu**
 - Project and Gantt properties
 - Labels management
 - User fields management