Mobile pictograms (v6 features)

Create phasing

- Introduction
- Drawings management
- GIS management
- Areas and axes management
- Print areas management
- Tasks management
- Connected objects management
- **Mobile pictograms (v6 features)**
- The Gantt chart
- The Live View (v6 features)

The mobile pictograms are only useful for work **on axis**.

They are intended to move dynamically with the segments of the axis which are being executed.

The video below illustrates the benefit of mobile pictograms:

Video

_

_____

Prerequisites :

_____

For mobile pictograms to be of interest, the following conditions must be met:

- **Having created axis** on the base plans (see addition of axis)
- **Have associated an axis** with an activity **AND** this association has a **mobile execution** (see Multizone, impact, right-of-way (RoW) and execution mode)

Create a profile :

Creating a profile is done from the **Options menu - Manage mobile pictogram profiles**

Add and set an image in the profile :

Once the profile is created, you will be able to add as many images inside as needed. To do this, select the profile in the left side panel and then click on the + in the right panel.

For each image, you will have to define different attributes:

Nom	Image	Vertical	Placement	Rotation	Pos. Absolue	Taille	Unité	+

- The **name** to more easily identify your image,
- **Vertical** positioning in order to position the pictogram above, below or on the segment,
- The **location** to determine if the pictogram will be at the beginning, in the middle or at the end of the segment or its extent,
- The **rotation** as well as the **absolute/relative position** of the pictogram in relation to the orientation

Projet Linéaire
12 impasse Bernard Lyot
85 000 LA ROCHE-SUR-YON
Tél. : +33(0) 2 22 44 52 52
support@projetlineaire.com

Fiche support imprimée le 2025/04/16 20:00

of the segment,

The **size** of the pictogram **in the unit of your choice**.

Associate a pictogram profile with an activity :

The association of a pictogram profile with an activity is done from the tab **Zones** in the activity editing window.

The association is therefore made at the level of the axis and for the pictogram to be mobile, the Execution must be MOBILE on the axis :

If you try to add a profile to a zone, it simply won't work:

Preview of the result in Live View:

To observe the result, the most direct way is to launch the Live View as shown in the animation below. For more information on LIVE VIEW, go to Live View (new in v6)